color

Protocol for shipping COVID-19 samples to Color

Document Contents

- 1. Important Notes on Shipping and Turnaround Time
- 2. Fedex Shipping Schedule Considerations
- 3. Materials included for sample shipment
- 4. Packing your samples for shipping



Important notes on shipping and turnaround time:

- All samples must be kept at or below room temperature, but above freezing, for the entire duration of collection and shipping.
- Results will be available 1-3 days after the samples arrive at Colo
- Samples should be shipped overnight the same day they are collected.
- A delay in shipping samples will result in a delay in results and the possibility of the samples expiring.

FedEx shipping schedule considerations:

- Shipments should be sent via FedEx Priority Overnight.
- Please contact FedEx to determine the latest pick-up or drop-off time for each day.
 FedEx Drop Boxes should not be used.
- Shipments Monday Friday will arrive the next day if dropped off/picked up by the FedEx Priority Overnight cutoff time using the included labels.
 - Note: In the case of Friday shipments, "Saturday delivery" is selected.
- FedEx Priority Overnight does not apply on weekends or national holidays.
 - Shipments on Saturday arrive on Monday with the included label. Please be aware that scheduled pick-ups may not be available and FedEx drop-off locations may have limited hours.
 - Sunday shipments are discouraged.
- You may need a different FedEx label if you require special shipping arrangements.
- Please contact covidshipping@color.com with any shipping questions.



Materials included for sample shipment*:

- Large biohazard bag
- Absorbent mat for the bottom of large biohazard bag
- Ice packs (2 per shipment, should be frozen at least 48 hours ahead of time)
- Insulated box liner
- Cardboard box with return Priority Overnight shipping label and UN 3373 sticker already affixed.

Packing your samples for shipping

- 1. Place individual samples (packaged in their small clear plastic bag) in a large biohazard bag with the absorbent pad at the bottom. Note: The biohazard bag should not contain more than 50 samples.
- 2. Tie the bag closed with a knot.
- 3. Open the insulated box liner, forming a square bottom, and place it inside the cardboard box with the shipping labels.
- 4. Place one frozen ice pack on the bottom of the insulated liner. Then put the biohazard bag and the second frozen ice pack on top.
- 5. Close the insulated liner by peeling off the backing of the adhesive strip and sealing the liner, ensuring a tight seal. Tuck the edges inside the cardboard box.
- Seal the cardboard box.
- 7. Provide box to FedEx.

^{*} Please plan your shipments based on the number of shipping materials you purchased. No more than 50 samples should be shipped in a single box.